

ENGLISH



DEPRESSURIZATION INSTRUCTIONS


POLYKEG PRO 2.0



Before proceeding, please also carefully consult the warnings in 'Section 1' of the Polykeg PRO 2.0 user manual and the keg technical sheet available in the 'Download' section of the PolyKeg website.

1 Depressurization procedure with OPRV

At the end of use, disconnect the keg from the system and depressurise it by breaking the release valve before disposing of it at a collection point. Pull the red lever outwards and cause it to break as shown in the figure.



2 Depressurization procedure with Key

If preferred or in the absence of a red lever valve, the keg can be depressurised using the depressurisation key as shown in the figure. The key is compatible for all PolyKeg valve types: A, D, G, K, M, S.

